

ELECTRICAL CATALOG

PIGTAILS & HARNESSES

NOVEMBER 2025



PIGTAILS B	Y PIN COU	NT	
2 pin			
	Y APPLICA		
DURAMAX			<u>18-20</u>
HARNESSES	S		
<u>All Harnesses</u>			



PIGTAILS 1 PIN



Duramax Oil Pressure Sensor - LB7 (2001-2002) FPE-HAR-DMAX-OP-0102



Starter Solenoid (2003-2018) FPE-HAR-CUMM-ST-PT-0318

PIGTAILS 2 PIN



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INJ-PT



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INJ-PT-4P



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INI-PT-8P



Sensor Connector for L5P Duramax and GM Vehicles FPE-HAR-MU-PT-1



Cummins Multiuse Sensor Pigtail 2 FPE-HAR-MU-PT-2



Cummins Temperature Sensor Pigtail FPE-HAR-CUMM-IAT-PT



Fuel Pressure Regulator and Multiuse Pigtail FPE-HAR-FPR-PT



Fuel Heater Connector and Pigtail for Cummins 5.9L/6.7L FPE-HAR-CUMM-FH-PT



Multiuse Sensor Pigtail 5

FPE-HAR-MU-PT-5

PIGTAILS 2 PIN



Multiuse Sensor Pigtail 8
FPE-HAR-MU-PT-8



Multiuse Sensor Pigtail 11

FPE-HAR-MU-PT-11



Multiuse Sensor Pigtail 10 FPE-HAR-MU-PT-10



Camshaft Position Sensor Ford 6.0L/6.4L Powerstroke FPE-HAR-FMC-CAM-0310



Alternator Pigtail for RAM with Cummins (2007-2022) FPE-HAR-CUMM-ALT-0722



WIF Sensor Pigtail for 6.7L Powerstroke (2011-2019) FPE-HAR-FMC-WIF-PT-1116

5



Transmission Input Speed Sensor Pigtail FPE-HAR-MU-PT-14



Lift Pump Pigtail for Ford Powerstroke (2011-2016) FPE-HAR-FMC-LP-1116

PIGTAILS 3 PIN



Cummins Crankshaft and Camshaft Sensor Pigtail FPE-HAR-CUMM-CC-PT



Cummins 5.9L VP Crankshaft and Camshaft Sensor Pigtail FPE-HAR-CUMM-VP-CC-PT



Rail Pressure Sensor Pigtail

FPE-HAR-RP-PT



Cummins Crankcase Pressure Sensor Pigtail FPE-HAR-CUMM-CCP-PT



Turbocharger Turbine Speed Sensor Pigtail *FPE-HAR-CUMM-SP-PT*



Duramax MAP/BARO Sensor Pigtail (2001-2007) FPE-HAR-DMAX-MAP-0107



Duramax Oil Pressure Sensor Pigtail (2003-2010) FPE-HAR-DMAX-OP-0310



Duramax Crankshaft Position Sensor Pigtail *FPE-HAR-DMAX-CPS-0416*



Cummins Multiuse Sensor Pigtail 3 FPE-HAR-MU-PT-3

6

PIGTAILS 3 PIN



Multiuse Pressure Sensor Pigtail FPE-HAR-MU-PT-6



Cummins Multiuse Sensor Pigtail 9 FPE-HAR-MU-PT-9



Multiuse Sensor Pigtail 13

FPE-HAR-MU-PT-13



Exhaust Back Pressure Sensor Pigtail FPE-HAR-EXBP-2020-PT

PIGTAILS 4 PIN



Cummins Multiuse Sensor Pigtail 4 FPE-HAR-MU-PT-4



MAP Sensor and Airbox Control Valve Pigtail FPE-HAR-MU-PT-7



Sending Unit Pigtail for Ford Powerstroke (1999-2007) FPE-HAR-MU-PT-15



Cummins 5.9L MAP Sensor Pigtail FPE-HAR-CUMM-MAP-0307-PT



LB7 Outer Injector Harness Pigtail FPE-HAR-DMAX-LB7-INJ-PT



Duramax Vane Position Sensor Pigtail (LLY) *FPE-HAR-DMAX-VPS-0405*



Duramax Vane Position Sensor Pigtail (LBZ,LMM,LML) FPE-HAR-DMAX-VPS-0616



MOPAR Pressure Sensor Pigtail FPE-HAR-MOPAR-PS-0209



Holset HE300VG Turbocharger Actuator Pigtail FPE-HAR-CUMM-VGT-PT

8

PIGTAILS 4 PIN



MAF Sensor Pigtail for 6.7L Cummins FPE-HAR-CUMM-MAF-PT



Lift Pump Pigtail for Ford Powerstroke (2017+) FPE-HAR-FMC-LP-1724



Valve Cover Injector Pigtail (2003-2005) FPE-HAR-CUMM-INJ-0305-PT



MAP Sensor Pigtail for 6.7L Cummins (2007.5-2018) FPE-HAR-CUMM-MAP-0718-PT

PIGTAILS 5 PIN



Cummins Cooling Fan and Clutch Pigtail (MY 2013-2022) FPE-HAR-CUMM-CF-1322



Fuel Rail Pressure Sensor Pigtail (2013-2024) FPE-HAR-CUMM-RP-SEN-PT



EGR Cooler Bypass Valve Pigtail (2013-2022) FPE-HAR-CUMM-EGR-VL-PT



MAF Sensor Pigtail for LML Duramax (2011-2016) FPE-HAR-DMAX-MAF-1116-PT

PIGTAILS 6 PIN



Injector Connector with Pigtail for Cummins 5.9L/6.7L FPE-HAR-CUMM-INJ-PT



Cummins Cooling Fan and Clutch Pigtail (2003-2012) FPE-HAR-CUMM-CF-0312



Cooling Fan Pigtail for Ford Powerstroke (2020+) FPE-HAR-FMC-FAN-20-PT



Neutral Safety Switch Connector Pigtail FPE-HAR-CUMM-NSS-PT



Transmission / Throttle Valve Connector Pigtail FPE-HAR-CUMM-TTVA-PT

PIGTAILS 8 PIN



Cummins EGR Valve Pigtail FPE-HAR-CUMM-EGR-PT

PIGTAILS 12+ PIN



GM Automatic Transmission 20-Pin Pigtail FPE-HAR-GM-AT-20-PT



Heated Seat Module Connector Pigtail FPE-HAR-HSM-PT



NSBU Pigtail for GM with Allison Transmission (2004.5-2005) FPE-HAR-GM-NSBU-0405



Injector Harness Pigtail for LM2/LZ0 3.0L Duramax FPE-HAR-LM2-INJ-12P-PT

APPLICATION CUMMINS



Starter Solenoid (2003-2018) FPE-HAR-CUMM-ST-PT-0318



Cummins Multiuse Sensor Pigtail 2 FPE-HAR-MU-PT-2



Cummins Temperature Sensor Pigtail FPE-HAR-CUMM-IAT-PT



Fuel Heater Connector and Pigtail for Cummins 5.9L/6.7L FPE-HAR-CUMM-FH-PT



Multiuse Sensor Pigtail 5
FPE-HAR-MU-PT-5



Alternator Pigtail for RAM with Cummins (2007-2022) FPE-HAR-CUMM-ALT-0722



Cummins Crankshaft and Camshaft Sensor Pigtail FPE-HAR-CUMM-CC-PT



Cummins 5.9L VP Crankshaft and Camshaft Sensor Pigtail FPE-HAR-CUMM-VP-CC-PT



Rail Pressure Sensor Pigtail

FPE-HAR-RP-PT

14

APPLICATION CUNINS



Cummins Crankcase Pressure Sensor Pigtail FPE-HAR-CUMM-CCP-PT



Turbocharger Turbine Speed Sensor Pigtail *FPE-HAR-CUMM-SP-PT*



Cummins Multiuse Sensor Pigtail 3 FPE-HAR-MU-PT-3



Multiuse Pressure Sensor Pigtail FPE-HAR-MU-PT-6



Cummins Multiuse Sensor Pigtail 9 FPE-HAR-MU-PT-9



Cummins Multiuse Sensor Pigtail 4 FPE-HAR-MU-PT-4



MAP Sensor and Airbox Control Valve Pigtail FPE-HAR-MU-PT-7



Cummins 5.9L MAP Sensor Pigtail FPE-HAR-CUMM-MAP-0307-PT



MOPAR Pressure Sensor Pigtail FPE-HAR-MOPAR-PS-0209

15

APPLICATION CUMMINS



Holset HE300VG Turbocharger Actuator Pigtail FPE-HAR-CUMM-VGT-PT



MAF Sensor Pigtail for 6.7L Cummins FPE-HAR-CUMM-MAF-PT



Valve Cover Injector Pigtail (2003-2005) FPE-HAR-CUMM-INJ-0305-PT



MAP Sensor Pigtail for 6.7L Cummins (2007.5-2018) FPE-HAR-CUMM-MAP-0718-PT



Cummins Cooling Fan and Clutch Pigtail (MY 2013-2022) FPE-HAR-CUMM-CF-1322



Fuel Rail Pressure Sensor Pigtail (2013-2024) FPE-HAR-CUMM-RP-SEN-PT



EGR Cooler Bypass Valve Pigtail (2013-2022) FPF-HAR-CUMM-FGR-VI-PT



Injector Connector with Pigtail for Cummins 5.9L/6.7L FPE-HAR-CUMM-INJ-PT



Cummins Cooling Fan and Clutch Pigtail (2003-2012) FPE-HAR-CUMM-CF-0312

16

APPLICATION CUNNINS



Neutral Safety Switch Connector Pigtail FPE-HAR-CUMM-NSS-PT



Transmission / Throttle Valve Connector Pigtail FPE-HAR-CUMM-TTVA-PT



Cummins EGR Valve Pigtail FPE-HAR-CUMM-EGR-PT



Rail Pressure Sensor Pigtail FPE-HAR-RP-PT

APPLICATION DURANAX



Duramax Oil Pressure Sensor - LB7 (2001-2002) *FPE-HAR-DMAX-OP-0102*



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INJ-PT



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INJ-PT-4P



Fuel Injector Connector for L5P Duramax FPE-HAR-L5P-INJ-PT-8P



Sensor Connector for L5P Duramax and GM Vehicles FPE-HAR-MU-PT-1



Fuel Pressure Regulator and Multiuse Pigtail FPE-HAR-FPR-PT



Multiuse Sensor Pigtail 8
FPE-HAR-MU-PT-8



Multiuse Sensor Pigtail 11

FPE-HAR-MU-PT-11



Multiuse Sensor Pigtail 10

FPE-HAR-MU-PT-10

18

APPLICATION DURAMAX



Transmission Input Speed Sensor Pigtail FPE-HAR-MU-PT-14



Rail Pressure Sensor Pigtail

FPE-HAR-RP-PT



Duramax MAP/BARO Sensor Pigtail (2001-2007) FPE-HAR-DMAX-MAP-0107



Duramax Oil Pressure Sensor Pigtail (2003-2010) FPE-HAR-DMAX-OP-0310



Duramax Crankshaft Position Sensor Pigtail *FPE-HAR-DMAX-CPS-0416*



MAP Sensor and Airbox Control Valve Pigtail FPE-HAR-MU-PT-7



LB7 Outer Injector Harness Pigtail FPE-HAR-DMAX-LB7-INI-PT



Duramax Vane Position Sensor Pigtail (LLY) *FPE-HAR-DMAX-VPS-0405*



Duramax Vane Position Sensor Pigtail (LBZ,LMM,LML) *FPE-HAR-DMAX-VPS-0616*

19

APPLICATION DURANA



MAF Sensor Pigtail for LML Duramax (2011-2016) FPE-HAR-DMAX-MAF-1116-PT



GM Automatic Transmission 20-Pin Pigtail FPE-HAR-GM-AT-20-PT



Heated Seat Module Connector Pigtail FPE-HAR-HSM-PT



NSBU Pigtail for GM with Allison Transmission Injector (2004.5-2005) FPE-HAR-GM-NSBU-0405



Harness Pigtail for LM2/LZ0 3.0L Duramax FPE-HAR-LM2-INJ-12P-PT

APPLICATION POWERSTROKE



Multiuse Sensor Pigtail 8

FPE-HAR-MU-PT-8



Camshaft Position Sensor Ford 6.0L/6.4L Powerstroke FPE-HAR-FMC-CAM-0310



WIF Sensor Pigtail for 6.7L Powerstroke (2011-2019) FPE-HAR-FMC-WIF-PT-1116



Lift Pump Pigtail for Ford Powerstroke (2011-2016) FPE-HAR-FMC-LP-1116



Multiuse Sensor Pigtail 13 FPE-HAR-MU-PT-13



Exhaust Back Pressure Sensor Pigtail FPE-HAR-EXBP-2020-PT



Sending Unit Pigtail for Ford Powerstroke (1999-2007) FPE-HAR-MU-PT-15



Lift Pump Pigtail for Ford Powerstroke (2017+) FPE-HAR-FMC-LP-1724



Cooling Fan Pigtail for Ford Powerstroke (2020+) FPE-HAR-FMC-FAN-20-PT

21

APPLICATION POWERSTROKE



Heated Seat Module Connector Pigtail FPE-HAR-HSM-PT

FLEECE PERFORMANCE HARNESSES



Bosch CP3 Regulator Extension Harness FPE-HAR-CP3-EXT



Crankshaft and Camshaft Sensor Extension Harness FPE-HAR-CUMM-CC-EXT



Cummins MAP Sensor Adapter Harness (MY 2002) FPE-HAR-CUMM-ADPT-MAP-02



Intake Air Temperature Sensor Extension Harness FPE-HAR-67-IAT-EXT



Turbo Vane Position Sensor Adapter Harness (LLY) FPE-HAR-DMAX-VPS-ADPT



Internal Wire Harness Connector Seal (GM) FPE-HAR-GM-LCT-SEAL



Internal Wire Harness Connector Seal (GM) (7 Pack) FPE-HAR-GM-LCT-SEAL-7P



Valve Cover Conversion Harness (2006+ to 03-05) FPE-HAR-CUMM-VC-ADPT-LATE



Valve Cover Conversion Harness (03-05 to 2006+) FPE-HAR-CUMM-VC-ADPT-EARLY

23

FLEECE PERFORMANCE HARNESSES



Duramax Fan Extension Harness (LML) FPE-HAR-DMAX-FAN-LML



Duramax Fan Extension Harness (L5P) FPE-HAR-DMAX-FAN-L5P



Cooling Fan Extension Harness (2013-2018) FPE-HAR-CUMM-FAN-1318



Cooling Fan Extension Harness (2019-2024) FPE-HAR-CUMM-FAN-1924



Cooling Fan Adapter Harness for 6.7L Powerstroke (2011-2018) FPE-HAR-FMC-FAN-1118



Fuel Pressure Regulator (FPR) Wiring Harness FPE-HAR-DMAX-FPR



18" Rail Pressure Sensor Extension Harness FPE-HAR-RP-EXT



Fuel Rail Pressure Harness for LML 6.6L Duramax FPE-HAR-DMAX-LML-RP



Charging Circuit Harness for Ford 6.7L Powerstroke (2011-2016) FPE-HAR-FMC-CCH-1116

FLEECE PERFORMANCE HARNESSES



Charging Circuit Harness for Ford 6.7L Powerstroke (2017-2018) FPE-HAR-FMC-CCH-1718



Charging Circuit Harness for Ford 6.7L Powerstroke (2019) FPE-HAR-FMC-CCH-19



Charging Circuit Harness for Ford 6.7L Powerstroke (2020-2022) FPE-HAR-FMC-CCH-2022



Rail Pressure Sensor Harness for 2006-2010 6.6L Duramax FPE-HAR-DMAX-RP-0610